


WL401822H


SAFETY & CARE


- 1. To retain the best quality finish, clean product with a soft cloth and a mild soap solution.
- 2. Do not use abrasive or chemical cleaners as they may damage the surface of the toilet seat or hinaes.
- 3. Spray cleaning liquids onto the cloth and not directly onto the product.
- 4. Take care when cleaning the toilet pan with chemical cleaners. Avoid contact of the chemical cleaners with the toilet seat or hinges. Immediately rinse off any splashes to avoid damage or discolouration to the surface of the toilet seat and hinge parts.




















FOR CLEANING

Look to step 3 for instructions on how to utilise the quick release function which allows you to remove the seat for cleaning.







+44 (0) 1264 365881



+44 (0) 1264 356437



info@croydex.co.uk

