



White/Chrome Shower Seat

Installation Instructions





IMPORTANT

- It is advisable to keep these instructions in a safe place for future reference.
- Shower seats are only as strong as the wall to which they are fixed and the fixings that are used.
- For different wall types you will need to ensure that you are using the correct type of fixing for the material of the wall.
- The addition of backboards on the outside of the wall or appropriate strengthening of internal structures may be required to provide adequate wall strength.
- NOTE: If the wall is made of lightweight thermal blocks, aerated hollow brickwork or prefabricated partitions even the most appropriate fixings may not be able to withstand the loads which can be suddenly applied to shower seat.

GENERAL SAFETY INSTRUCTIONS

- It is recommended that two people fit this product to ensure that it is fitted safely.
- Always take care when using power tools, particularly in the bathroom.
- Always check for hidden cables and pipework before drilling and take extreme care if there is any water in the working area.
- It is advisable to use a residual current circuit breaker (RCCB).
- Always wear suitable eye protection when drilling.
- If the product is to be fitted on a ceramic tiled wall, a ceramic drill bit should be used.
- Always ensure that the drill hole passes through the central tiled area rather than through the grouted area. To prevent damage to the tile, mask the area around the hole with tape before drilling.
- Do not strike the product with hard or sharp objects.

TOOLS REQUIRED NOT SUPPLIED

Drill and Masonry Bit		Pencil	
Screwdriver		Tape Measure	
Appropriate Fixings	 x 5	Spirit Level	

ASSEMBLY INSTRUCTIONS

1. Identify the most appropriate position for the shower seat ensuring the product is at a comfortable height and distance for showering.
2. The product can be folded upwards for more convenient storage so please ensure there is sufficient space above the fixing position to allow for this.
3. Place the shower seat in the desired position on the wall and using the hole centres located on the wall bracket as a template, mark the screw fixing positions on the wall surface, ensuring the product is level.

ALL FIXING HOLES MUST BE USED (See Fig.1).

4. Drill the holes in the marked positions using a masonry drill. If the product is to be fitted onto a ceramic tiled wall, a ceramic drill bit should be used.
5. Insert wall plugs (if applicable) flush to the surface of the wall. If fitting to a tiled surface, the wall plugs should be inserted below the surface of the tile to avoid cracking.
6. Insert the fixings through the holes located on the wall bracket and secure to the wall.

NOTE: Do not use countersink screws. Do not enlarge fixing holes. This can reduce the strength of the frame and invalidate the safe working load stated.

7. Once secured in position, clip the chrome cover plate over the wall bracket to conceal the wall fixings and complete the assembly of the shower seat - See Fig.2

8. Always check the shower seat is securely fastened to the wall before use.

This product must only be fitted to solid brick, concrete block walls or similarly strong materials offering appropriate support for the maximum safe working load.

Maximum safe working load for the shower seat is 100kg




Fig.1

NOTE:
Wall fixings for
reference only!




Fig.2

CARE & MAINTENANCE

- To retain the best quality finish, clean product regularly with a soft damp cloth.
- Do not use abrasive or chemical cleaners as these will damage the product.

We have taken great care to ensure that this product reaches you in perfect condition. However should any parts be damaged or missing please contact your point of purchase. This does not affect your statutory rights. In addition if you require replacement parts your point of purchase will be happy to assist.